Assembly Instructions


Garment Bag

Contents:


· Bag with nylon zipper

• Metal frame with hanger assembly • Maxi Rack • (3) three hooks

Working from inside the bag, place the metal frame at the top of the bag. **NOTE:**Make sure the center cross bar is not between the wire frame and the top of the bag. Slide one (1) hook through the hole in metal frame then through the center metal gromment on the top of the bag. Hang on a closet rod or similar support to finish assembly.



Working from inside the bag, slip two (2) of the hooks through loops on the Maxi Rack then through the metal grommets at the to of the bag.



For Assistance or Parts Call 1-800-446-3880 • Richards Homewares, Inc.